

**Divator DP-1 and DP-2 Apparatus
Configuration**

Component	Drawing number	Part Number
Regulator with warning device	55 153 B	99 083 01
Regulator P+	96 720 E	96 720-51
T piece	346 190 093 D	346 190 093
Hose (71 meter)	96 725 P	99 086-03
"Octopus" Breathing valve	55 113	97 199 02
Surface Box		
Valve Block	96 711 J	346 190 329 (with PSI gauge)
Whistle insert	96 711 J	346 190 404
Shuttle inset	96 711 J	460 190 709
Hose (1 meter)	96 711 J	96 116-01
Connection manifold	96 711 J	96 786
Venting valve 300 BAR	96 711 J	96716
Spare parts list, Divator		99578C01
Divator SCUBA users manual		99841A01
Divator maintenance & repair manual		336100529B01
DP-1 user manual		96708E01
DP-1 spare parts list		99036E01
DP-1 maintenance & repair manual		99037E01